



The STA Setup method

操作说明


User Guide

By Allen, January 17,2022


www.gainscha.com.tw

The WIFI Module STA setup method

1. Connect to your computer via the USB and open the PrinterUtility
2. Read the printer and WiFi information, (must support WiFi)



3. Select STA Mode Note: (AP-Printer Launch WiFi; STA Printer Connect WiFi)



4. Press [Win + R] to enter “cmd”, and enter “ipconfig” + “Enter” to query the IP



5. The IP address, gateway address, and subnet mask in the PrinterUtility must be consistent with the desired WiFi connection. **Note: (The IP address does not conflict with other connected devices)**




Note (The last IP value cannot be the same as the WiFi, otherwise there will be a conflict, and you can enter any successful ping value.)

6. Enter the WiFi name and password-set.




7. Remember the port number as shown below:




Note: Open the USB interface

8. Restart the printer, use PrinterUtility to select WiFi connection mode-Find device.**Note:(The printer does not need to connect to the computer via the USB).**



9. Enter the port number just noted and click Search for the following figure:



10. Select the searched IP address, and click "select" to read the printer information in the figure below:



11. If the reading is successful, the WIFI module STA is complete.